


# eZ-NDT

version 6.0.9

Requires a 32-bit version of Windows®



Windows 2000 SP4  
Windows XP  
Windows Vista (x86)



372163C-01

1086-0924 rev 9.2

**Iotech**  
25971 Cannon Road  
Cleveland, OH 44146-1833  
(440) 439-4091  
Fax: (440) 439-4093  
sales@iotech.com  
productsupport@iotech.com  
**www.iotech.com**



# Contents

## 1 - Introduction

## 2 - Investigative Mode Testing

## 3 - Inspection Mode Testing

## 4 - Windows and Menus

**Main Window ..... 4-1**

**Graphical Display ..... 4-6**

**File Menu ..... 4-8**

**Edit Menu, Configuration ..... 4-10**

Acquisition Tab ..... 4-10

Input Channels Tab ..... 4-11

Automation Tab ..... 4-14

**Edit Menu, Limits ..... 4-17**

**Edit Menu – Display and General Options ..... 4-18**

Display Preferences .....4-18

Copy Window ..... 4-18

Load Picture .....4-18

Remove Picture ..... 4-18

Erase History File .....4-18

Erase Template File ..... 4-18

**Menus with Associated Window Panels ..... 4-19**

Project ..... 4-19

Control ..... 4-19

Display ..... 4-19

View ..... 4-19

**Report Menu ..... 4-20**

**User Menu ..... 4-25**

**Notes for Efficient use of eZ-NDT ..... 4-26**

## 5 - Setting Limits

*This page is intentionally blank.*

## System Requirements

Minimum requirements include:

- Monitor: SVGA, 1024 x 768 screen resolution
- **Requires 32-bit version of Windows:** Windows 2000 SP4, Windows XP, or Windows Vista (x86)  
Windows 2000 SP4 and Windows XP Users:  
PC with Intel™ Pentium 4 or equivalent; 1 GB memory; 10 GB disk space  
Windows Vista (x86) users:  
PC must be *Windows Vista Premium Ready*



### Reference Note:

If necessary, refer to your system's associated hardware manual for information regarding the following:

- Software Installation
- System Requirements
- Hardware Setup
- Driver Installation

---

## What is eZ-NDT?

eZ-NDT is a non-destructive QA/QC inspection system based on the ZonicBook FFT. High frequency vibration data is collected and compared against user-defined amplitude and frequency limits. A *passed* (good) part will have the maximum spectral peak(s) within the defined limit band(s). A *failed* (bad) part will have one or more spectral peaks outside the defined limit band(s).

eZ-NDT systems typically include a computer running a Microsoft Windows 2000 SP4 or Windows XP, an analyzer such as a ZonicBook FFT Analyzer, or an IOtech 640 or 650, one modal hammer, and one response instrument, such as a microphone or an accelerometer.

**Note:** The term “ZonicBook” refers to a ZonicBook-Medallion and/or a ZonicBook/618E device unless otherwise specified.

eZ-NDT has two modes: **Investigation** and **Inspection**.

The **Investigation Mode** is used to define the spectral acceptance regions. It is an iterative process that compares the spectral frequency and amplitude differences between known Good and Bad parts.

Limit bands are defined based on vibration peaks that occur in the tests of “good” parts, but not in the tests for “bad” parts. After the limits are defined all the parts are tested to ensure that:

- all the “good” parts pass and
- all the “bad” parts fail

Some fine-tuning may be required.

When test results are consistent, you are ready to start testing production parts in the Inspection Mode.

Typically, good parts should have a consistent spectral response, in other words, a good repeatable pattern. A shift or change in spectral pattern indicates a change in the part's Mass, Stiffness, or Damping. These changes often indicate a problem with the part.



- **To ensure repeatable results make certain that setup conditions are consistent; for example: the Impact Location and Force of hammer strike.**
- **When an automated system is used, there are additional process considerations. These are typically addressed and configured at the factory prior to shipment.**


Multiple user levels exist for project protection. Level 3 is for the manager and allows complete access to the System. Level 2 is for the technician and Level 1 is for the inspector. Levels 1 and 2 do not permit configuration modifications, among other limitations.

The first time eZ-NDT is executed it will automatically load the default configuration parameters into the “Project Template”. The template is located in the Windows directory in which eZ-NDT was installed .

You should consider an “eZ-NDT Project” equal to a unique Part that you wish to test. For example, if you manufacture Widgets and Gizmos, you would have 2 separate eZ-NDT projects, one for Widgets and one for Gizmos.

Each eZ-NDT project is saved in one project file with the extension “.ndt.” Thus the widget project could be named “widget.ndt” and the gizmo project could be named “gizmo.ndt”.

Each eZ-NDT project is saved in one project file with the extension “.ndt.”



### *eZ-NDT, Operation Sequence*

1. Gather known “good” and “bad” parts .....2-1
2. Set up the analyzer, hammer, microphone, and computer ..... 2-1
3. Launch eZ-NDT ..... 2-2
4. Open a New eZ-NDT Project ..... 2-3
5. Select Investigation Mode ..... 2-4
6. Configure the Analyzer ..... 2-4
7. Select Plot Display Type ..... 2-4
8. Turn on Data Acquisition .....2-4
9. Test All Good Parts ..... 2-4
10. Test All Bad Parts .....2-6
11. Compare the Results of Good and Bad Tests .....2-7
12. Configure the Limits ..... 2-7
13. Verifying the Limits and Ranges ..... 2-9

The following process can be used to determine whether eZ-NDT testing is feasible for the part that is being tested. Typically this is an iterative process in which the user:

- establishes the resonant signature of the part
- determines the distinct peaks of the signature
- uses the peaks to set up eZ-NDT test criteria




- To ensure repeatable results make certain that setup conditions are consistent; for example: the Impact Location and Force of hammer strike.
- When an automated system is used, there are additional process considerations. These are typically addressed and configured at the factory prior to shipment.

---

## 1. Gather known “good” and “bad” parts.

Locate both good and bad parts. Typically 10 of each are sufficient. Make sure the Bad parts include all possible *reject* (failure) modes. The good parts will be used to test for NDT feasibility.



*Block Diagram of Typical NDT Setup*

---

## 2. Set up the analyzer, hammer, microphone, and computer.

Connect your analog input signals to the analyzer (e.g., ZonicBook/618E, 640, or 650 device) BNC inputs. Configure the analyzer as needed.



### Reference Note:

If necessary, refer to your hardware user's manual as applicable for information regarding:

- Software Installation
- System Requirements
- Hardware Setup
- Driver Installation

- a. Connect the Impact Hammer to Channel 1.
- b. Connect the Microphone to Channel 2.
- c. Place the microphone within range of the output.

---

## 3. Launch eZ-NDT.

To run eZ-NDT, double-click the eZ-NDT icon or use your Windows desktop Start button to navigate to the program file.

### First Time Running eZ-NDT


### *Registration Form*

**Note:** After you have completed the following steps, each succeeding time that you start eZ-NDT you will be taken immediately to the main screen.

A registration form will open the first time you run eZ-NDT. You must complete the information in this form to enable the eZ-NDT application.

The password accompanies your CD-ROM. You will not have to re-enter this information again, unless you upgrade to a newer version, or have to re-install eZ-NDT.

eZ-NDT will open to its main screen, as indicated below.



*eZ-NDT Main Window*

#### 4. Open a New eZ-NDT Project.

Each eZ-NDT Project contains configuration and data files. You should logically equate an eZ-NDT project with a specific part that you wish to inspect.



Because multiple eZ-NDT Projects will exist on your computer we suggest you create project folders to organize and save your files. These folders can be located anywhere on your system.

- a. On the File menu select New Project to open the “Save As” window.
- b. Select a folder for your eZ-NDT Project or create a new folder.



*Save As Dialog*

If you created a new folder...

With “New Folder” highlighted, type a name for the Project Folder. Then, double-click on the folder to open it. This is where you will save your new project files.

- c. Type a filename for the project, including the file extension, in the File name data entry box.  
i.e. part234.ndt



**DO NOT use NDT.ndt as a filename. NDT.ndt is the default template. A good file name is on that identifies the part, for example, part232.ndt.**

- d. Click the Save button to create the new project. Now all the files for this project will be saved in the folder you just used.

---

## 5. Select Investigation Mode.

On the main screen select Investigation Mode.



---

## 6. Configure the Analyzer.

To start use the default values.



**If you have tested both good and bad parts, and you do not see a difference between them, you may need to modify one or more of the configuration values. Increasing the Trigger Delay is the most common solution.**

---

## 7. Select “Spectrum/FRF Display” as the Plot Type.



The plot display types are selected by clicking on one of the first two buttons. The first button on the left is “Spectrum / FRF Display.” The second button is “Time Display.”

For our “Investigation Mode” we want to use the “Spectrum/FRF Display” for the type of plot. Click on the Spectrum icon (first button).


---

## 8. Turn on Data Acquisition.

To initialize the hardware and turn on the data acquisition, click the red toggle switch in the Acquisition panel of the Main window. The toggle switch will flip up and change from red to green. Prior to proceeding, wait for the status to change from “Initializing Hardware” to “Ready.”




## 9. Test all “Pass” (Good) Parts.




### *Investigation Mode, Pass Part Template*

To test all “Pass” (Good) parts:

- Select the Pass parts in the grid (see figure, upper right). Note that you can right-click on a part number, e.g., “1” to access its associated template.
- Strike the parts several times at a consistent location with a consistent amount of force.
- If you do not see anything on your plot, click on the <Autoscale> button, or the <Log Scale Y Axis> button, to expand the y-axis.




**Use of the logarithmic scale (Log Scale Y Axis button) tends to enhance the peaks. This makes it easier determine significant peaks.**




### *Linear Scale of Initial Strike*

- Click the Autoscale button to have the Y axis minimum and maximum scaled to the data



*Autoscale of Initial Strike (Logarithmic Scale)*

## 10. Test all “Fail” (Bad) Parts.



*Investigation Mode, Fail Part Template*

To test all “Fail” (Bad) parts:


- Select the “Fail” parts in the grid (see figure, upper right). Note that you can right-click on a part number, e.g., “1” to access its associated template.
- Strike the parts several times at a consistent location with a consistent amount of force.
- If you do not see anything on your plot, click on the <Autoscale> button, or the <Log Scale Y Axis> button, to expand the y-axis.

## 11. Compare the Test Results of Pass and Fail Parts.

Visually locate the spectral differences between the Pass and Fail parts. You should be looking for resonant peak(s) that shift in frequency (e.g., red lines to the left or right of the blue line) and/or amplitude (red lines shorter or taller than the blue line). If blue and red peaks are almost identical, they are probably not good choices. Ideally you will find significant single peaks.



**Because this process detects internal, non visible defects, you may have an occasional part fail, which you thought was a “Pass” part.**



*Using Investigation Mode, Comparing a Good Part to a Bad Part*

## 12. Configure the Limits.

Modify the limit bands to match the “Pass” part’s spectral peaks that you want to use. As mentioned earlier, this is an iterative process. Quite often, some of your “Pass” parts will fail with these exact limits the first time.

eZ-NDT will find the maximum spectral amplitude in a frequency range. If this point is in the defined limit region, the range status is “Pass.”


The default step includes four limit bands, already placed on the plot. These limit bands are green acceptance limits [peaks for subsequently tested parts must be within these limits to be counted as “Pass” parts]. Working from left to right, drag the first band to the first peak you want to use. Next, drag the second band to the second peak you want to use, etc.



If you do not need all four of the limit bands, remove the extra ones. Instructions for removing and adding limit bands follow.


**To remove a Limit Band from the plot:**

- Right-click on the Limit Band's associated letter. Each enabled limit band has a letter in a white box (see figure).  
A property box will appear. In the figure below Limit D is being selected.
- Remove the checkmark from "Enabled."
- Click the <Apply> button.



**Removing a Limit Band**

**Note:** Limit bands can also be added or removed via the "Limits" selection within the Edit pull-down menu. The difference in using the Edit menu's "Limits" selection is that all properties (for all limit bands) are displayed at the same time [instead of one at a time]. See following figure.



**Limit Values Window, Partial Display**

Limit Bands can be "Enabled" and "Disabled" from the first column.

**To add a Limit Band to the plot:**

- Right-click on a disabled Limit Band's associated letter. Note that disabled limit bands are designated as letters in gray boxes  
A property box will appear.
- Add a checkmark to the "Enabled" property.
- Click the <Apply> button. The new limit band will appear on the plot display.

**Note:** Limit bands can also be added or removed via the “Limits” selection within the Edit pull-down menu. The difference in using the Edit menu’s “Limits” selection is that all properties (for all limit bands) are displayed at the same time [instead of one at a time].

**Note:** Up to ten limit bands can exist on a plot.


---

### 13. Verify the Limits and Ranges.

- a. Switch to Investigation Mode.
- b. Test all the known “Pass” (Good) and “Fail” (Bad) parts. Look for consistent results.

#### **If parts pass and fail as expected . . .**

You are ready to run tests on production parts. If this is the case ensure that the “Graphical Limit Changes are Disabled” (locked padlock) image is showing (following figure). If the padlock image is open, click on it to lock in the limit bands at their current settings.



**Graphical Limit Changes  
are Disabled**

#### **If good parts fail and/or bad parts pass . . .**

*Are any peaks just a fraction out of range?* If so, tweak those limits.

*Are there peaks that you missed the first time?* Add one or more limit bands.

*Are there two peaks that are fairly close, one within the band and one just outside it?*

Sometimes you will have 2 closely spaced peaks. These peaks will “fight” for dominance.


In this type of case you can either:

- remove the entire range
- widen the range to include both peaks, or
- split the range with one peak in each range.


- c. Re-test the known “Bad” parts. *Did they all fail?*

If not, consider setting amplitude limits. Sometimes, the only difference between a good and bad part is a difference in amplitude of a significant peak.

You can change the amplitude and/or frequency limits of band by: (1) unlocking the “Graphical Limit Changes” button, (2) placing the mouse cursor over the limit edge to be changed, (3) stretching or shrinking the band to the desired new limit. (4) repeat steps 2 and 3 for the other limits of the band, as desired. An example follows.



Graphical Limit Changes are Enabled.



**Three Views of Limit Band "A"**

The third view shows the band after high and low amplitude limits have been adjusted. The third view also shows that Low and High Frequency Limits can be adjusted.

**If, following adjustments, you still can't distinguish between "Good" and Bad parts . . .**

Try changing the Pre/Post Trigger Delay Percentage value of the trigger channel. By increasing this value, you are delaying the start of the sound measurement. This delay can be very helpful identifying cracked parts, because a cracked part can not hold a tone. The resonant frequencies of a cracked part die out quickly.

- 1. **Launch eZ-NDT** ..... 3-1
- 2. **Open the eZ-NDT Project** ..... 3-1
- 3. **Turn on the Analyzer** ..... 3-1
- 4. **Test Parts** ..... 3-2
- Reviewing NDT Inspection Results** ..... 3-3
- Preparing Reports** ..... 3-4



A feasibility test and setup of the test parameters must be completed prior to starting production testing.

---

## 1. **Launch eZ-NDT.**

To run eZ-NDT, double-click the eZ-NDT icon or use your Windows desktop Start button to navigate to the program file.

---

## 2. **Open the eZ-NDT Project.**

Select Open Project on the File Menu. Find the project of interest and double-click on it. This will open the project and set up the test parameters.

---

## 3. **Turn on Analyzer.**

Click the Red toggle switch in the Acquisition panel of the Main window. This will initialize the hardware, for example a ZonicBook/618E, 640, or 650, as applicable. Wait for the Ready status.



*Acquisition (Off)*



*Acquisition (On)*


## 4. Test Parts.

If you are using an automated system, start the conveyor and start loading parts onto the conveyor.

If you are using a manual system, strike the part, at the prescribed location, with the hammer.  
eZ-NDT performs the inspection process when the “Force” channel’s trigger conditions are met.

After you strike the part, check the Hammer Status message in the Acquisition Panel and the Status Panel.  
If your hammer strike resulted in a Trigger, you will see the NDT inspection results, PASS or FAIL.

**Note on Performance Speed:** Each part may take from 1-2 seconds to test under Level 3. For quicker results switch to Level 1 (graphics are not updated).



### *Using Inspection Mode to Compare a Production Part to a Known Bad Part*

**Troubleshooting:** If the Trigger did not occur, you need to verify one or more possible causes.

- There is a hardware problem. Check the trigger channel’s cable connections. If this instrument requires ICP verify the configuration settings.
- There is a configuration problem. Check the trigger channel’s FSV and Trigger Percentage. The input trigger voltage may be lower than the configuration settings. If you are operating at the Technician or Operator level, you will need to change the User Level to Manager to check and make changes to the configuration settings. Clicking the “Reset/Set Default” button will normally correct any problems.

## Reviewing NDT Inspection Results

Item	Description
1	Lists eZ-NDT Projects
2	Shows a picture of the part
3	Resets the counts to zero
4	Displays name of company and part number. The 2 fields are edited from the Acquisition Tab under Edit / Configuration.
5	Serial number
6	Name of inspector
7	Automatically increments the serial number.
8	Pass: Displays the quantity of parts that passed. Fail: Displays the quantity of parts that failed. Curr: Displays the number of parts that have consecutively passed or failed since the end of the previous sequence. For example: If we had 56 parts in a row pass, Curr would display "56 Pass," If the next part failed Curr would display "1 fail." If the very next part failed Curr would display "2 fail" etc.

**Project Panel**

The Project Panel contains the NDT inspection results since the last time the <Reset Summary Counts> button (3) was pressed. The total number of Passed and Failed parts, as well as the consecutive count, are listed (8).

The Since label displays the date and time that the <Reset Summary Counts> button (3) was last clicked. The <Reset Summary Counts> button clears the entries for Passed, Failed, Current (Consecutive Count), and resets the date and time [under the Since label]. Clicking the button does not erase the data stored in the history file.


Note that the date and time of the last NDT inspection is displayed in the upper left corner of the panel.

---

## Preparing Reports

After each NDT inspection, the test results are stored in the history file. This is a FIFO, “First-In, First-Out” file.

eZ-NDT is capable of generating three types of reports from this history file: **Production**, **Plot Data**, and **Configuration Settings**.



### *Report Pull-down Menu*

The reports are text files. After selecting a report type, you will be prompted to enter a filename for the text file using a standard Windows dialog box. The features of the three report types are as follows:

**Production Report** – After choosing **Production** from the **Report** menu, a production report dialog box opens. It displays two radio buttons, allowing the user to choose either a Summary or Detailed production report.

- The Summary report lists the inspection status of each part tested over the selected date and time range. The serial number and inspector name is also listed.
- The Detailed report, in addition to the information contained in the summary report, also provides the measured frequency and amplitude peak for each spectral band on a given response channel.
- Both the Summary and the Detailed Report provide a statistical summary at the bottom of the report. The statistical summary lists the counts, average, and standard deviation values for both Passed and Failed parts.

To the right of the production report dialog box is a graphic and a sliding scale, which both represent the amount of data held in the project’s history file. The sliding scale allows the user to choose the amount of data which will appear in the report. To use the sliding scale:

1. Click on the green start arrow and drag it to the desired starting percentage. The date and time of the first data point will be displayed at the bottom of the scale.
2. Click on the red end arrow and drag it to the desired ending percentage. The date and time of the final data point will be displayed at the top of the scale.
3. Click the <Okay> button.

For example, if you wanted to generate a report using only the last 50% of the history file, you would drag the green arrow to between “40” and “60” on the scale, and drag the red arrow to “100”. To use the entire history file, leave the green arrow at “0” and the red arrow at “100”.

**Plot Data Report** – Choosing **Plot Data** from the **Report** menu generates a list of all the data points (using x and y coordinates) that are displayed on the graph. The units used for the x and y coordinates in the report will depend on whether the graph was set to the Time display or Spectrum/FRF display.

eZ-NDT can also generate a **Configuration Settings** report, which lists many of the configuration options that are set in the analyzer’s configuration screen (accessible by selecting the **Edit** menu, and then the analyzer hardware).

- Main Window ..... 4-1**
- Graphical Display ..... 4-6**
- File Menu ..... 4-8**
- Edit Menu, Configuration ..... 4-10**
  - Acquisition Tab ..... 4-10
  - Input Channels Tab ..... 4-11
  - Automation Tab ..... 4-14
- Edit Menu, Limits ..... 4-17**
- Edit Menu – Display and General Options ..... 4-18**
  - Display Preferences .....4-18
  - Copy Window ..... 4-18
  - Load Picture .....4-18
  - Remove Picture ..... 4-18
  - Erase History File .....4-18
  - Erase Template File ..... 4-18
- Menus with Associated Window Panels ..... 4-19**
  - Project ..... 4-19
  - Control ..... 4-19
  - Display ..... 4-19
  - View ..... 4-19
- Report Menu ..... 4-20**
- User Menu ..... 4-25**
  
- Notes for Efficient use of eZ-NDT ..... 4-26**

## Main Window


Test-specific information is located in the Project Panel. The panel includes Company Name and Part Name (4), Serial Number (5), and Inspector's Name (6). Pass/Fail information is included (8).

Item	Description
1	Lists eZ-NDT Projects
2	Shows a picture of the part
3	Resets the counts to zero; resets the "Since" time to computer clock date and time.
4	Displays name of company and part number. The 2 fields are edited from the Acquisition Tab under Edit / Configuration.
5	Serial number
6	Name of inspector
7	Automatically increments the serial number.
8	Pass: Displays the quantity of parts that passed. Fail: Displays the quantity of parts that failed. Curr: The current consecutive part.

This information is stored with the data after each NDT inspection. Company Name and Part Name are set up in the Acquisition Tab of the Configuration window [selected from the Edit pull-down menu].

The part's Serial Number and the Inspector's Name can be manually entered in the text fields. A picture of the part being tested can be overlaid using the <Show Picture> button (2). To load a graphic for the first time, or to change a previously loaded graphic:


- Left-click on the <Show Picture> button (2). A "Part Picture" pop-up window appears.
- Right-click on the "Part Picture" pop-up window. A "Load Graphic Picture" context menu appears.
- Left-click on the "Load Graphic Picture" menu. An "Open" window appears.
- Use the "Open" window to browse for your part image (.jpg or .bmp format). Then open the image.
- You can re-size and reposition the part image.



*Main Window with Part Image Displayed*


## Acquisition Panel with Mode Selection

The Acquisition Panel includes an ON/OFF toggle switch, two icon-buttons, and two radio buttons. The toggle switch turns the acquisition “on” or “off.” The <Reject Last Test> button [at the panel’s upper right] is for discounting and rejecting the last test, regardless of whether it was a Pass or a Fail. The lower button, with the musical note image, is for playing a sound after each production test, or for turning that sound off.




*Acquisition Panel*

The two radio buttons for selecting the mode of operation. **Investigation Mode** is for feasibility testing and Limit Configuration. **Inspection Mode** is for normal testing of production parts.



*Mode Panel, Investigation Mode Selected*



*Mode Panel, Inspection Mode Selected*


On eZ-NDT start-up, this button is blank. After each NDT inspection, the button’s color and status message reflect the inspection results. Red indicates a failed part. Green indicates a good part. Click on this button to view the entire spectral range.

**Channels:** <Channel> buttons are shown vertically from 1 to 8. Both Force and Response channels can be displayed in either the Time or Spectrum format. Unused channels are not enabled (dimmed).

**Limit Range Buttons:** The horizontal numbered buttons show the NDT inspection status for the defined limit ranges. Red indicates fail. Green indicates pass. Up to 10 ranges exist for each response point. To display a range of interest, click on the desired <range> button. To view the full scale, press the <Overall Part Status (PASS/FAIL)> button. To return to the original X-axis scale, click on the <Overall Part Status> button again.

Clicking on a <Limit Range> Button expands the graphical display to show that particular Frequency and Limit Range.

## Digital I/O Panel



*Digital I/O Panel*

The Digital I/O Panel is used with the optional digital I/O control package. It is associated with the Configuration window's Automation tab, which is discussed later in this chapter.

The Digital I/O panel's toggle switch controls the ON/OFF status of the eZ-NDT Automation Module. The four Relay Icons indicate the current status of the relays.

Each time you start the NDT software, the Automation main switch is turned "off." You must turn the switch "on" to send output to the relay channels.


The relay channels can be set to trigger according to:

- the state of a channel
- the number of consecutive fails
- the acquisition status


You can test a relay by clicking on its associated button.

Note that if Digital Inputs have been enabled, the digital input status will be present in the label above the output relay buttons.

## Display Toolbar




*Display Toolbar*

Button	Function												
Spectrum/ FRF Display	Sets the window to display data with the x-axis scaled to frequency and the y-axis scaled to dB or engineering units, depending on the setting in the Acquisition tab of the Configuration window.												
Time Display	Sets the window to display data with the x-axis scaled to time and the y- axis scaled to dB or engineering units, depending on the setting in the Acquisition tab of the Configuration window.												
Auto Scale	Automatically adjusts the scale. Auto scale will be either enabled or disabled. When enabled, the Y axis scale is 20% greater than the data range. When disabled, the Y-axis scale is defined by the instrument range in the configuration.												
Log Scale Y Axis	Only applies to Spectrum/FRF Display. This sets the y-axis to a logarithmic scale. Note that Time displays are always linear.												
Cursor	<p>Click the Show Cursor Values Icon to open a floating display of the cursor values. Click on the upper left corner of the display to move it anywhere on the screen. Values are displayed in the x, y format.</p>  <table border="1"> <thead> <tr> <th>X</th> <th>Y</th> </tr> </thead> <tbody> <tr> <td>2268.8</td> <td>0.00</td> </tr> <tr> <td>5712.5</td> <td>0.00</td> </tr> <tr> <td>7700.0</td> <td>0.00</td> </tr> <tr> <td>11319.</td> <td>0.00</td> </tr> <tr> <td>0.00</td> <td>7.0000</td> </tr> </tbody> </table> <p>Cursor values exist for each defined limit range. The cursor is automatically positioned to the highest peak in the limit range. You can move the cursor by dragging it across the graph with your mouse or by using the keyboard. The “,” (comma)” key moves the cursor Left. The “.” (period)” keys move the cursor Right</p>	X	Y	2268.8	0.00	5712.5	0.00	7700.0	0.00	11319.	0.00	0.00	7.0000
X	Y												
2268.8	0.00												
5712.5	0.00												
7700.0	0.00												
11319.	0.00												
0.00	7.0000												
Show Frequency Ranges	Uses vertical lines to identify High and Low Frequency Limit Ranges for the Spectrum / FRF display.												
Graphical Limit Changes (Enable / Disable)	<p>When the padlock image is unlocked, limit bands can be adjusted with a mouse as described in chapter 2’s step 13.</p>  <p>When the padlock image is locked, limit bands cannot be altered. This feature prevents limits from being accidentally changed.</p>												

# Graphical Display

## Limit Range

The Graph displays the results of a strike. The acceptance limit regions are shaded in green; failure limit regions are shaded red.



**Graph Displaying Three Acceptance Limit Regions**


The Limit Range cells are used to access a specific Limit Band (lettered A through J). Right-clicking on a Limit Range cell brings up a properties box, which allows you to change Limit Band parameters and Low and High Frequency Range limits. Left-clicking on a cell focuses in on the limit aspect for the associated band. Note that you can also select a Limit Band from the View pull-down menu.

Click in a Limit Range cell to see the limit range for the limit band.

Click in the Channel Identifier to return the window to full view.

Note: Right-click in the Limit Range cell to bring up the Limit Band's properties box.

Limit Setup	Value
Enabled	<input checked="" type="checkbox"/>
Limit Type	
X Axis	
Low X Range	6323.6
Low X Limit	7058.0
High X Limit	7516.9
High X Range	9561.5
Peak Type	
Low Y Limit	0.00
High Y Limit	33.012



**Adjusting Low and High Frequency Range Limits for Cell B**


## Modifying Limits from the Main Window

**Add Limit Band:** Using your mouse, right click on a Limit Range cell. Check “enabled,” then click the <Apply> button.

**Remove Limit Band:** Using your mouse, right click on a Limit Range cell. Un-check “enabled,” then click the <Apply> button.

**Moving the Limit Band:** To move a limit band, first unlock the Graphic Limits with the padlock icon button; then select the desired Limit Range cell. Using your mouse, right-click anywhere within the band. At this point you’ll see a crosshair. While pressing the right mouse-button, move the crosshair to the new x-axis position. The Limit Band will relocate.

**Changing the High and Low Frequency Range Limits:** First unlock the Graphic Limits with the padlock icon button; then select the desired Limit Range cell. Next place the mouse cursor of the vertical line of the High or Low range limit. “HFR” or “LFR” will appear in a box (see preceding figure). Use the double-arrow to adjust the limit. Note that you can also use the properties box to adjust the range limits, as discussed on the previous page.



*Adjusting the Low Frequency Range Limit*

Other limit modifications include increasing or decreasing

- Limit Band Frequency
- Limit Band Amplitude

Adjustment of the Limit Band Frequency and Amplitude is discussed and illustrated in chapter 2, in the section titled, *13. Verify the Limits and Ranges*.

## Magnifying Areas on Graph

**X-axis:** Hold down the <Ctrl> key, then left-click and drag the cursor lines across the area of interest.

**Y-axis:** Hold down the <Alt> key, then left-click and drag the cursor lines across the area of interest.

**Both axes:** At the same time, hold down the <Ctrl> and <Alt> keys while you draw a cursor box around the area of interest.


In each of the above cases the x and y axis scales will automatically change to reflect the new view. Click the <Auto Scale> button in the Display Toolbar to zoom back out to a full view.

---

## File Menu

### New Project

When you select New Project, the “Save As” window opens. If you already have a project defined, it will open to the folder where that project is saved. You can create the new project here, or you can create a new folder in which to save your project.




*Save As Dialog*

1. Select New Project on the File menu.
2. Find the folder in which to save this project, or create and name a new folder.
3. Type a file name (including the extension).
4. Click the <Save> button.

### Open Project

The Open Project command, opens the “Open” window.



*Open Project Dialog*

1. Select Open Project on the File menu.
2. Find the folder in which your project was saved.
3. Click the <Open> button.



If you have an older EZ-NDT project with multiple files (i.e., files with extensions “.ndt1”, “.ndt2”, etc.), they will be combined into one file (with a “.ndt” extension) once the latest version of the EZ-NDT.exe is used to open the old “.ndt1” file.

### Save Project

This menu item save the current state of your project.

## Save As...

This menu item opens the Save As window. Enter a new path and file name for this project. Use this command to save setup time on a new project if it is very similar to a current or older project.



*Save As Dialog*

## Print

The Print command prints the Main window.

## Exit

Quits the NDT application. This can be performed only when the User level is Manager.

## Edit Menu

### Configuration . . .




This menu option is only available at Level 3 operation AND when Data Acquisition is OFF.

The Configuration window includes three Tabs: Acquisition, Input Channels, and Automation. A discussion of each follows.

### Acquisition Tab

This tab provides a means of setting acquisition parameters and preferences. It includes a means of adding Company and Part Number association. The 4 left-side panels are self-explanatory and will not be discussed other than to state that dB is typically used for the Y-axis scale. In regard to the Calculation panel, FRF is generally preferred for getting data from multiple parts quickly; Spectrum mode should be used for small numbers of parts, or slower acquisitions.



The Configuration Window, "Acquisition" Tab

### Acquisition Parameters Panel

#### Analysis Frequency (Hz)

Select the desired Analysis Frequency. This value is the maximum frequency of interest. The sampling rate will be 2.56 times the analysis frequency. Verify the maximum frequency response of your probes. Typically, the analysis frequency will be 20 KHz. [Default: 20 KHz.]

#### Block Size

Select the desired Block size. This value is the number of samples per block of data. For example, a 2048 Block size contains 2048 data samples and will produce an 800 line spectrum. A larger Block size will provide you with greater data resolution. However, it will require more time to collect a block of data.

#### No. of Averages


The number of data blocks used in the NDT analysis. Typically, the number of averages is set to one.

## Preferences Panel

- Investigation Samples** Used to specify the number of samples to be used in the investigation mode. Up to ten samples can be selected. On the main window, these will appear as numbers 1 through 10 in the Pass Fail columns.
- File Size (FIFO Records)** Enter the desired File Size. The required hard disk space for the requested file size is displayed to the right of the data entry box and cannot exceed 2.1 gigabytes. Data is stored to the history file after each NDT analysis.
- Test Result Flashes** The number of times the results of each test will flash on the screen.
- Display HPF (Hz)** Sets a frequency limit for the display window, such that all data at that frequency and lower will be displayed as “0.” Thus, only data above the HPF value will be displayed.

## Input Channels Tab

The Input Channels Tab allows you to state the channel type (Trigger or Response), name the channel, and set the channel parameters. Channel attributions can be copied and pasted to other channels.



*The Configuration Window, “Input Channels” Tab*

## Input Channels Tab

- No.** Used to select the channel to be configured.
- Type** Select the instrument Type on the pull down menu. Types include Force, Response, and Unused. You must have 1 Force Channel and 1 or more Response Channels. [Default: Channel 1 is the Force channel; channel 2 is the Response channel; channels 3 through 8 are unused.]
-  **Users of ZonicBook-Medallion only:** Configure the Dip Switches located under the ZonicBook-Medallion Input Module for each probe. Typically, Hammers, Microphones, and Accelerometers are Single Ended, AC Coupled, and ICP On.
- Name** Enter a Name label for the channel; e.g., Trigger, Response, Microphone.
- FSV (+/-)** Double-click on the cell and select the maximum Full Scale Voltage expected for the instrument. Erroneous results will occur if you select a voltage value that is less than the actual input voltage.
- ICP** Used for ICP transducers. Checking “ICP” sources a bias current through the center conductor of the input channel BNC connector.

## Input Channels Tab

<b>Cplg</b>	Selects AC or DC coupling.
<b>mV/EU</b>	Use to set the instrument's input sensitivity. Typically, sensitivities are as follows: <ul style="list-style-type: none"><li>• Accelerometers: 100 mV per g</li><li>• Microphones: 25 mV per Pa</li><li>• Hammers: 1 mV per lbf.</li></ul>
<b>Min Y</b>	Min Y is used to set the instrument <i>minimum</i> in engineering units.  [Default: Force Units are lbf (pounds force) for modal hammers; G's for accelerometers; and Pa for microphones.]
<b>Max Y</b>	Max Y is used to set the instrument <i>maximum</i> in engineering units
<b>Units</b>	Used to identify the Engineering Units (EU) for the channel. The user is free to enter whatever unit name he or she prefers. Typical units are: dB, lbf, Pa.
<b>Trigger (%)</b>	Used to set the percentage value of the full scale voltage at which the force (hammer) signal must reach before it is recognized as a trigger event.  Each trigger event results in a test inspection. For example, if the FSV for the instrument is 1.000 V and the Trigger Percentage is 10%, eZ-NDT will trigger acquisition when the Force Input is 0.100 V.
<b>Delay (%)</b>	Used to define the start of the data block as a percentage of the block size from minus 100% to plus 100 %.  A positive value will result in a <i>Post Trigger</i> . This is recommended for most applications.  A negative value will result in a <i>Pre-Trigger</i> . For example, entering "-10" defines a <i>Pre-Trigger that is 10% of the block size</i> . This means that 10% of the data block will occur <i>prior to the trigger event</i> .

---

## Input Channels Tab

**FFT Window** Used to select the type of FFT Window:

Used to select the desired FFT Window function for the input channel. Choices are None, Hanning, Flat top, Exponential, and Force.

When using FFT, one must be careful to avoid potentially serious errors due to "FFT leakage." When this occurs, a signal at one frequency spreads out ("leaks") over a wider frequency range in the FFT spectrum.

Intuitively, leakage arises from cutting out a finite length "window" of data from a longer continuous signal. This causes an apparent discontinuity at the ends of the data block. It has nothing to do with the actual signal. These "truncation" errors can be effectively controlled, *though not completely eliminated*, by multiplying each data frame by a suitable time-domain weighting-window that smoothly attenuates the data near the ends of each block, prior to performing the FFT.

**None:** Select "None" if you want the display to have no window function.

**Hanning:** The Hanning window offers a reasonable trade-off of frequency accuracy versus amplitude accuracy.

**Flat Top:** This window has a very low peak amplitude error, and its frequency resolution is somewhat better. Its side lobes are considerably higher. Its effective noise bandwidth is still almost twice that of the Hanning window, therefore this window is used mainly to measure accurate peak amplitudes of discrete spectral components that usually separated by at least several spectral lines.

**Exponential:** An Exponential weight window is equal to 1.0 at the beginning of the block and decays exponentially to a smaller value at the end of the block. Exponential is used only with transient data that is captured with pre-trigger to assure that the initial values in all data channels are very close to zero. Exponential can be used with all transient excitation methods in order to force the signals to decay close to zero, even if the block length is not sufficient to capture all of the naturally occurring response. If the data decays naturally to a low amplitude within the block, so that leakage is not significant, exponential windowing can improve the signal-to-noise ratio by giving reduced weight to the very low-amplitude data at the end of the block.

**Force:** This is a rectangular function that helps to ensure a consistent force is applied to each part.

## Input Channels "Edit..." Pull-down Menu

**Set Defaults** Returns the channel configuration to the original factory settings.

**Copy Channel (Ctrl + C)** Copies the configuration of a channel into memory. Used in conjunction with Paste Channel or "Ctrl + V".

**Paste Channel (Ctrl + V)** Used to paste a channel configuration that was copied with Copy Channel or "Ctrl + C".

**Fill Down (Ctrl + D)** Copies and pastes the setting of a selected cell to all active cells directly below it. See note.

**Fill Up (Ctrl + U)** Copies the setting of a selected cell up to all active cells directly above it. See note.



**Edit Menu,  
for Input Channels**




**If the selected cell is a response channel and a force channel is above or below it, the force channel configuration will be overwritten.**

## Automation Tab

The “Automation” Tab is used for Automation Module (NDT Relay Module) applications. The tab has two or three panels, depending on the hardware used. This is explained shortly.

**Digital I/O Hardware Panel** – This panel allows you to select the model number of the digital I/O hardware and the RS232 COM Port number which it is connected to. In regard to the hardware model number: if “NDTRelay2” is selected the Digital Inputs panel will be visible, as indicated in the following figure. If “NDTRelay1” is selected the Digital Inputs panel will not appear on the tab.



*The Configuration Window, “Automation” Tab*

**Digital Outputs Panel** – Use this panel to configure the responses of your eZ-NDT Automation Module. This device will allow you to have relay switches open and close based on the results of each test. You can use up to four relays.



**Normally the configuration settings defined during the feasibility study are used. Please do not deviate from these unless you are an advanced technician.**

The color of the response channel indicates the pass (green) or fail (red) status of the part. If the response channel relay is normally open (green) when a part passes inspection the relay will remain open. On the other hand, if the response channel relay is normally open and a part fails, the relay will close for the duration specified by the time; and then it will reopen.

Additionally, you can have the system count the number of consecutive fails and change the relay status when a specified number of consecutive failures is reached.



Relays can be manually triggered in the Relay Output panel of the Main window by clicking on a Relay Icon.

**Digital Inputs Panel** – This pane, located at the bottom half of the screen, is not displayed for NDTRelay1. The panel allows you to set different eZ-NDT projects to run automatically when triggered to do so by a digital pattern. This allows the process to inspect multiple part types, each of which uses a different eZ-NDT configuration.

## Digital Outputs Panel

No.	Active	NO / NC	Timer	Type	Count	Ch 1	Ch 2	Ch 3	Ch 4
1	<input checked="" type="checkbox"/>		5.00	 123	5				
2	<input checked="" type="checkbox"/>		8.00						
3	<input checked="" type="checkbox"/>		12.00						
4	<input checked="" type="checkbox"/>		0.50						

*The Automation Tab's Digital Outputs Panel*

- No.** The relay number. Up to 4 relays can be used.
- Active** Check a box to make the associated relay active. Remove the checkmark to disable the relay.
- NO / NC** Used to set the relay's normal operating state to open or closed, i.e., "Normally Open" or "Normally Closed."
- Timer** Sets the time that the relay switch will stay in its triggered state, before returning to its normal open or closed position. For example, for Relay No. 1 above, after 5 parts failed the switch would open for 0.5 seconds, then close again.
- Type**
-  Checks the "Count" number, which is entered in the adjacent column to the right. The switch state changes when the number of failed parts equals the count number. When the timer value is reached the switch will return to its normal closed state.
  -  Response Channel State. *Triggers on a non-normal condition.* This mode compares the actual part status (good or bad) against the condition indicated in the Digital Output panel. When the part condition matches the indicated setting, the relay switch leaves its normal state. For example, with Relay Number 2 [above] when Ch 1 and Ch 2 both fail, the normally closed switch will open. When the timer value is reached the switch will return to its normally closed state.
  -  Manual trigger. The relay switch will remain in its normal state until manually changed.
- Count** Sets the number of consecutive failures. Used in conjunction with the "count" type.
- Ch 1**  
**Ch 2**  
**Ch 3**  
**Ch 4** Ch 1 through Ch4 cells are used to set a channel's trigger condition in relation to the "good" or "bad" state of a part. In the example above, Relay No. 2 will stay closed as long as channel 1 and channel 2 have passed parts. If either or both have a failed part the condition triggers the Relay switch to open. When the timer value is reached the switch will return to its normal state.

## An Example of Automation Relays at Work, Using the Response Channel Type


When the result of the part is equal to the result indicated by the Digital Outputs panel, the operating state of the associated relay changes and a signal is sent to the relay switch.

Conversely, when the result of the part does not equal the result indicated by Digital Outputs panel, the state remains unchanged and no signal is sent to the relay switch.


In this example, assume that we want all tested parts (good and bad) to be sent by conveyor to one of two processes. Good parts go to finishing and bad parts go to rework.

We don't want a failure of the relay switch to result in bad parts being misdirected to the finishing process. Therefore we set up the conveyor so that the path to finishing is *normally* blocked, that is, it will be block when there is no power to the relay. That path is only to open for reception of good parts.

In the following gate-related figures, Good parts are designated with a "G" and Bad parts are designated with an "X."



The relay is "de-energized" (normally open) and the gate prevents entry to Finishing. The relay must be energized (by seeing a good part) in order to open the gate.



The relay is "energized" and the gate to finishing is open until the timer times out. Good parts keep the relay energized, therefore keeping the gate open to "finishing."

### Example of an Automation Relay being used to Control a Gate


This means that the relay switch should be **normally open** (no current). When a good part activates the relay switch, the switch closes. This sends power to open the gate to finishing. A bad part does nothing to the relay. For bad parts the relay remains open and the gate to finishing remains without power. The bad parts proceed on to rework. See the above diagrams.

Digital Outputs									
No.	Active	NO / NC	Timer	Type	Count	Ch 1	Ch 2	Ch 3	Ch 4
1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	5.00				<input checked="" type="checkbox"/>		

*Digital Setup for the Example*



The timer must be set to allow enough time for one good part to pass through the open gate. If a good part is followed by a bad part, the gate must be able to close in time to prevent entry of the bad part.



The Limit Values Window

The Limits Value window is used to configure the limit criteria for each input signal. You can define up to 10 limit ranges per response channel. Simply select the channel of interest; then define the range and limit values. You can copy attributes of one range to another via the window's Edit menu.

### Limit Values

<b>CH</b>	The Channel number.
<b>Name</b>	This is the response channel for which you will be setting limits. Typically there is only one Response Channel.
<b>ID</b>	For each significant peak you wish to monitor there should be a letter ID which has a defined range and limits. IDs are lettered A through J.
<b>Enabled</b>	Check the box to enable an ID. Remove the checkmark to disable the ID.
<b>Limit Type</b>	Sets the limit as a "pass" limit or a "fail" limit. Typically green and red.
<b>X Axis</b>	Select the Spectral Graphic Image for Frequency (Hz) or Select the smooth Sine Wave Graphic Image for Time-based (seconds). Frequency is the most often used scale for the display's X-axis.
<b>X LO Range</b>	Enter the lower and upper limit values of the frequency range.
<b>X HI Range</b>	eZ-NDT will find the maximum peak within this range.
<b>X LO Limit</b>	Enter the upper and lower limits range.
<b>X HI Limit</b>	<b>For a green limit:</b> if the frequency of the maximum spectral peak for the frequency range is within the Limits range, the part passes. <b>For a red limit:</b> if the frequency of the maximum spectral peak for the frequency range is within the Limits range, the part fails.
<b>Peak Type</b>	Select the graphics image of peak rising or peak falling.
<b>Y LO Limit</b>	Enter the lower and upper limit values for the Amplitude.
<b>Y HI Limit</b>	<b>For a green limit:</b> if the amplitude of the maximum spectral peak for the frequency range is within the amplitude range, the part passes. <b>For a red limit:</b> if the amplitude of the maximum spectral peak for the frequency range is within the amplitude range, the part fails.

## Limits Tab - Edit Menu

- Copy Channel (Ctrl+C)** This command copies the configuration of a channel into memory. Use the Paste Channel command to paste the values to another channel.
- Paste Channel (Ctrl+V)** This command pastes to a select channel the configuration of a channel previously copied with the Copy Channel menu item.
- Clear Limit** This command clears the row in which a selected cell resides. If no cell is selected, the top row is cleared.
- Clear ALL Limits** This command clears the entire configuration grid.




---

## Edit Menu – Display and General Options

### Edit Menu ...

#### Display Preferences



*Display Preferences Window*

The Display Preferences window is used to change eZ-NDT's display colors. As can be seen in the above figure, the window is self-explanatory.


- Copy Window (Ctrl+C)** This option copies the current window so it can be pasted into another application such as Microsoft Word or Excel.
- Load Picture** When documentation is required for your project a picture of the part being tested is useful. If you have a picture of your part (.jpeg or .bmp format), select this command to place it in the main window. The image can be positioned anywhere.
- Remove Picture** Remove picture removes the graphic from the main window.
- Erase History File** These two commands each function as a file delete key. Depending on the option used: all history data or all template data will be permanently deleted.
- Erase Template File**

## Menus with Associated Window Panels

The following menus have functionality that is typically accessed directly from a main window panel. For details regarding functions, please refer to the associated panel information. References are provided in the following table.

### Menus with Associated Window Panels

**Project** The Project pull-down menu offers the same functionality as the Project Panel found in the upper left corner of the main display window. Refer to page 4-2 for details.



**Project Menu**

**Control** Functions that can be initiated from the Control pull-down menu can also be initiated from the main window. However, in the main window the functions are divided by several panels.


Acquisition Panel  
 Digital I/O Panel  
 Inspection Mode Panel  
 Investigation Mode Panel

Control related information begins on page 4-3.




**Control Menu**

**Display** Items in the Display pull-down menu relate directly to the main window's toolbar as can be seen by comparing the two figures. Function details begin on page 4-5.





**Display Toolbar (On Main Window)**



**Display Menu**

**View** View provides a means of selecting Limit Range cells. This menu has the same functionality as the horizontal display of Limit Range cells found in the main window's Inspection Panel (lower figure). Details begin on page 4-3.




---

## Report Menu

eZ-NDT generates four reports.

### Generate a Production Report

The **Production** report contains the overall NDT inspection results for the specified time period. To generate a **Production** report:



*eZ-NDT Production Report Dialog*

1. Select **Production...** on the **Report** menu.
  2. The production report dialog is displayed.
  3. Select whether you would like to generate a **Summary** or **Detailed** production report by clicking on the appropriate radio button.
  4. Select the number of records to be included in your report by dragging the arrows up/down the scale.
  5. Press the **Okay** button.
  6. A save file dialog box will open.
  7. Type a name your report file in the filename data entry box. Use a unique name for each report.
  8. Click the **Save** button.
- After generating the report, eZ-NDT automatically opens the text file in Windows NotePad or WordPad.

## Summary...

The Summary Report contains the overall NDT inspection results for the specified time period. Statistical information is shown at the bottom of the report. The serial number and inspector name are also listed.

eZ-NDT v.5.0.43	
Project Path: C:\PROGRAM FILES\ZONIC\EZ-NDT\ndt	
Summary Report: 25-Oct-2001 08:57:03	
Requested Range: 25-Oct-2001 08:50:01 - 25-Oct-2001 08:54:20	
Company Name:	Your Company Name
Part No.:	Your P/N...
25-Oct-2001 08:50:01	FAILED
25-Oct-2001 08:50:05	FAILED
25-Oct-2001 08:50:10	FAILED
25-Oct-2001 08:53:10	FAILED
25-Oct-2001 08:53:11	FAILED
25-Oct-2001 08:53:13	FAILED
25-Oct-2001 08:53:14	FAILED
25-Oct-2001 08:53:15	FAILED
25-Oct-2001 08:53:18	FAILED
25-Oct-2001 08:53:35	FAILED
25-Oct-2001 08:53:36	FAILED
25-Oct-2001 08:53:39	FAILED
25-Oct-2001 08:53:44	FAILED
25-Oct-2001 08:53:48	FAILED
25-Oct-2001 08:53:52	FAILED
25-Oct-2001 08:53:54	FAILED
25-Oct-2001 08:54:04	FAILED
25-Oct-2001 08:54:06	FAILED
25-Oct-2001 08:54:18	FAILED
25-Oct-2001 08:54:20	FAILED
TOTAL PASSED:	0
AVERAGE PASSED:	0.00%
STD DEV PASSED:	
TOTAL FAILED:	20
AVERAGE FAILED:	100.00%
STD DEV FAILED:	
TOTAL:	20
AVERAGE TOTAL:	100%
STD DEV TOTAL:	

### *eZ-NDT Summary Report*

## Detailed...

The Detailed Report, in addition to the information contained in the summary report, provides the measured frequency and amplitude peak for each spectral band for each response channel.

eZ-NDT v.5.0.43													
Project Path:		C:\PROGRAM FILES\ZONIC\EZ-NDT\ndt											
Detailed Report:		25-Oct-2001 08:56:43											
Requested Range:		25-Oct-2001 08:50:01 - 25-Oct-2001 08:54:20											
Company Name:	Your Company Name												
Part No.:	Your P/N...												
25-Oct-2001 08:50:01	10044.00003	FAILED	Ch 02	F	1031.3	.00018	F	4056.3	.00006	F	7818.8	.00005	F
25-Oct-2001 08:50:05	12181.00003	FAILED	Ch 02	F	1231.3	.00019	F	4481.3	.00005	F	8131.3	.00004	F
25-Oct-2001 08:50:10	10806.00004	FAILED	Ch 02	F	1231.3	.00018	F	4556.3	.00006	F	8975.0	.00004	F
25-Oct-2001 08:53:10	10688.00003	FAILED	Ch 02	F	1625.0	.00017	F	4700.0	.00006	F	7443.8	.00004	F
25-Oct-2001 08:53:11	12125.00003	FAILED	Ch 02	F	1131.3	.00018	F	5018.8	.00005	F	7450.0	.00004	F
25-Oct-2001 08:53:13	10531.00004	FAILED	Ch 02	F	1231.3	.00020	F	4381.3	.00006	P	8243.8	.00005	F
25-Oct-2001 08:53:14	11375.00004	FAILED	Ch 02	F	1231.3	.00015	F	4037.5	.00006	F	9268.8	.00004	P
25-Oct-2001 08:53:15	10463.00004	FAILED	Ch 02	F	1231.3	.00015	F	4318.8	.00005	F	8025.0	.00004	F
25-Oct-2001 08:53:18	10769.00004	FAILED	Ch 02	F	1131.3	.00018	P	5250.0	.00005	F	9256.3	.00004	F
25-Oct-2001 08:53:35	10119.00004	FAILED	Ch 02	F	1231.3	.00016	F	4481.3	.00006	F	8056.3	.00005	F
25-Oct-2001 08:53:36	10350.00003	FAILED	Ch 02	F	1231.3	.00018	F	4006.3	.00006	F	7137.5	.00004	F
25-Oct-2001 08:53:39	10794.00004	FAILED	Ch 02	F	1231.3	.00018	F	4318.8	.00005	F	9987.5	.00004	F
25-Oct-2001 08:53:44	10119.00003	FAILED	Ch 02	F	1131.3	.00019	F	4481.3	.00006	F	8987.5	.00004	F
25-Oct-2001 08:53:48	10756.00005	FAILED	Ch 02	F	1231.3	.00018	F	4981.3	.00006	F	7381.3	.00005	F
25-Oct-2001 08:53:52	11644.00003	FAILED	Ch 02	F	1131.3	.00018	P	5550.0	.00005	F	7493.8	.00004	P
25-Oct-2001 08:53:54	12156.00004	FAILED	Ch 02	F	1231.3	.00018	F	4381.3	.00006	F	7043.8	.00004	F
25-Oct-2001 08:54:04	11094.00004	FAILED	Ch 02	F	1231.3	.00018	F	4718.8	.00005	F	7018.8	.00005	F
25-Oct-2001 08:54:06	11094.00004	FAILED	Ch 02	F	1231.3	.00017	F	4306.3	.00004	F	7350.0	.00004	F
25-Oct-2001 08:54:18	9987.500003	FAILED	Ch 02	F	1231.3	.00017	F	4381.3	.00006	F	9600.0	.00004	F
25-Oct-2001 08:54:20	12006.00003	FAILED	Ch 02	F	1231.3	.00017	F	4381.3	.00006	F	7112.5	.00004	F
TOTAL PASSED:		0	Ch 02	0			2			1			2
AVERAGE PASSED:		0.00%	Ch 02		0.00	0.00		5400.0	.00005		8243.8	.00005	
STD DEV PASSED:			Ch 02		0.00	0.00		150.00	11.1E-07		0.00	0.00	
134.38 25.6E-07													
TOTAL FAILED:		20	Ch 02	20			18			19			18
AVERAGE FAILED:		100.00%	Ch 02		1220.9	.00018		4443.8	.00006		8080.9	.00004	
STD DEV FAILED:			Ch 02		107.91	.00001		273.87	59.9E-07		935.71	35.7E-07	
727.93 45.1E-07													
TOTAL:		20	Ch 02	20			20			20			20
AVERAGE TOTAL:		100%	Ch 02		1220.9	.00018		4539.4	.00005		8089.1	.00004	
STD DEV TOTAL:			Ch 02		107.91	.00001		389.94	62.0E-07		912.71	35.7E-07	
716.14 43.8E-07													

### eZ-NDT Detailed Report

## Plot Data...

The **Plot Data** report generates a list of all the data points (using x and y coordinates) that are displayed on the graph. To generate a **Plot Data** report:

1. Select **Plot Data...** on the **Report** menu.
2. A save file dialog box will open.
3. Type a name your report file in the filename data entry box. Use a unique name for each report.
4. Click the **Save** button.

After generating the report, eZ-NDT automatically opens the text file in Windows NotePad or WordPad.

## Configuration...

The Configuration Report is a comprehensive listing of the project's parameters. It is a text file that can be saved and included with project documentation.

1. Select Configuration Settings... on the Report menu.
2. A save dialog will open.
3. Type a name your report file in the filename data entry box. Use a unique name for each report.
4. Click the Save button.

After it is generated, eZ-NDT will automatically open the report using Windows NotePad or WordPad. An example follows.

Company Name: Inspecto-Tech  
Part No.: GEAR CASE 104-A

ACQUISITION CONFIGURATION -----

Analysis: 20000 Hz  
Blocksize: 8192  
Averages: 1  
EU / dB: EU Amplitude  
Project Size: 100 Records  
Picture File: C:\\_PROJECTS\1086\ez-NDT\prop part image.JPG  
Password: NDT

INPUT CHANNELS CONFIGURATION -----

Channel 1: TRIGGER  
Name: Hammer  
Display Min: 0.00  
Display Max: 1.0000  
Eng. Units: lbf  
FS Voltage: .20000  
mV/EU: 1.0000  
FFT Window: Force

Trigger (%FSV): 10.000  
Trigger Delay (%): 5.0000

Channel 2: RESPONSE  
Name: Microphone  
Display Min: 0.00  
Display Max: 1.0000  
Eng. Units: Pa  
FS Voltage: .20000  
mV/EU: 25.000  
FFT Window: Hanning

LIMITS CONFIGURATION -----

Channel 2:

Freq Range: 935.80 8341.0 (Hz)  
Freq Limits: 1293.8 1798.3 (Hz)  
Amp Limits: 32.417 74.054

Freq Range: 5313.6 6093.1 (Hz)  
Freq Limits: 5575.1 5811.5 (Hz)  
Amp Limits: 0.00 58.331

DIGITAL IO CONFIGURATION -----

COM Port: 1

*Example of a Configuration Report*

---

## User Menu



**Remember your Level 3 password. If you go to Level 1 (Inspector), you will need the password to return to Level 3 (Manager).**

The current User Level is displayed in the lower portion of the Acquisition panel. There are 3 User Levels.

Level 3 (Manager) allows you complete access to all eZ-NDT features.


Level 1 (Inspector) enables minimal features. Typically you would use this feature if you have concerns regarding unauthorized access to your eZ-NDT Projects while the system is unattended.

# Notes for Efficient use of eZ-NDT

---

1. It will save you time, if you modify the NDT project in the executable's directory to match your standard configuration. Whenever you create a New Project, this project is the configuration template that is copied into your new project.
2. For ZonicBook-Medallion users only: Make sure the Dip switches are configured correctly. (Typically: Single Ended, AC coupled, and ICP ON.)
3. Use a standard channel location convention for your Force and Response channels. Typically: Force is channel 1 and Response is channel 2. Popular labels are: "Trigger" or "Hammer" for Force and "Microphone" for Response.
4. If you aren't getting a Trigger after you strike the part, verify the Force channel's FSV and Trigger Level Percentage.
5. A negative Pre / Post Trigger percentage will result in FRF calculations and limit checking. A positive Pre / Post Trigger percentage will use auto spectrum. Generally, you should use a positive Pre / Post Trigger percentage.
6. Some older versions of eZ-NDT created multiple project files (i.e., files with extensions ".ndt1", ".ndt2", etc.). If you wish to open an older file with newer versions of eZ-NDT which use only one file, simply open the old ".ndt1" file. This old project will automatically be converted to a single file with a ".ndt" extension.
7. **If for some reason, you have an error where eZ-NDT does not start.** You can work around the problem by deleting the file, "ndt.ini," located in the executable's directory. This file identifies the last Project opened. You can delete this file without affecting your data. Try reopening the last project.
8. If you still experience problems. Please send an email to [productsupport@iotech.com](mailto:productsupport@iotech.com).

Limits are defined frequency and amplitude ranges (where the resonances of a part will peak) across the x-axis. In our example, we impacted several known good parts and captured a sample resonance in the following display. We then placed cursors at the peaks we thought were significant. These same peaks may change in amplitude or shift frequency if a part is bad. Please note that significant peaks are not always the ones with the most amplitude. In fact, some of the peaks at lower amplitudes can be very significant because when they are below a certain amplitude it indicates that the part is “bad.”



*Significant Peaks*


Now that we know where the peaks are located, we can set the limit range in which they will appear.



Use the cursor values listed to the right of the plot to help you determine where frequency and limit ranges should be set.

Note that the first cursor is at 4250 and that there is another peak at approximately 4800, which we did not mark with a cursor. However, if a part is bad, that peak may shift down in frequency. Therefore, when setting our “good” limit, we must make sure that we set it low enough so that the resonance shift of the “bad” peak doesn’t create a peak within our “good” limits.

In our example we set the frequency range from 4050 to 4450 and the frequency limits between 4150 and 4350. Remember our “good” peak should be around 4250.



*Setting Limits using Significant Peaks*

